



Boot-Loader Connections

- D13
- D12
- D11
- VCC
- GND
- RESET
- RX
- TX



Arduino Programming Connections

- D13
- D12
- D11
- VCC
- GND
- RESET
- RX
- TX

